



SAMA

COMUTATORE MANUALE-AUTOMATICO
 SWITCH MANUAL-AUTOMATIC
 INTERRUPTEUR MANUEL-AUTOMATIQUE
 COMUTADOR MANUAL-AUTOMATICO

pos. 0: FERMO / STOP
 pos. 1: ALTA FIANMA / HIGH FLAME / ZWILLIG BEI ALTA FLAMA
 pos. 2: BASSA FIANMA / LOW FLAME / ZWILLIG BEI NIEDERER FLAMA
 pos. 3: AUTOMATICO / AUTOMATIC / AUTOMATIQUE / AUTOMATICO

WWW.SMARTFLAM.BY

Импортер
 в Республику Беларусь
 8 (029) 11 915 11 INFO@SMARTFLAM.BY

SERVOMOTOR LANDIS SQM 50.481A2 FLAME SENSOR UV	Ecoflam Bruciatori S.p.A R&D DEPARTMENT	DESCRIPTION BLU TS 8000.1-10000.1-12000.1-15000.1-20000.1-20000.1 PR SF (COMANDI) EQUIPMENT CREATION RBA11PC174	DESIGNER A-POZZOBON	DESIGNER SIGNATURE A. Pozzobon	SHEET 1
		ECOMODIFICATION RBA11PM070	CONTROLLER A-RCIONI	DATE OF CREATION 02-09-2011	TOT. SHEET 2
LANDIS LFL 1.333-1.622		CODE 420110069601			
DUNGS VPS 200		MODIFICATION DESCRIPTION			

BY TERM LANS WE RESERVE THE PROPERTY OF THIS WIRING DIAGRAM WITH PROHIBITION OF USE AND REPRODUCTION